

PocketBook®

User Manual PocketBook IQ 701



Table of Contents

Safety Precautions	5
Technical Characteristics	8
Appearance and Controls	9
Controls and Indicators	11
Getting Started	12
User Manual	13
Navigation	14
Selection of Items and Starting Applications	14
Home Screen	14
Status Bar	17
Panel of Running Applications	18
Using the On-Screen Keyboard	18
Software Functions	20
Library	21
Dictionary	26
Office Applications	27
Multimedia Content Management	27
Internet	28
File Manager	33
Advanced	35
Loading and Reading books	36
Loading Books to the Memory	36
Loading Protected Books (DRM)	36
Open a Book	38
Reading Mode	38

Settings.....48

Wireless & networks.....48

Sounds & display50

Applications51

Accounts & sync51

Privacy52

SD card and memory52

Language & keyboard53

Text-to-Speech53

Date and time53

About device54

Troubleshooting.....55

Customer Support.....58

Software Version Update.....59

Compliance with International Standards.....60

Thank you for purchasing PocketBook IQ 701!

Before you start using this PocketBook IQ 701 please read this Manual carefully. You will learn how to ensure your own safety and extend the service life of your device.

If any of the following safety measures have not been complied with or defects/faults are observed please contact the authorized service center to check your device. Failure to comply with this requirement may cause the device to malfunction.

Safety Precautions

Do not expose your device to excessively high or low temperatures. Avoid direct sunlight. Avoid heating or cooling the battery. An excessively hot battery may cause skin burns. Please note that the operating temperature range from 0°C to 40°C.

Avoid exposure to direct flame or smoke (cigarette, lighter, open fire etc.).

Avoid exposure to liquids or damp (do not use the device in the rain, in the street at higher humidity, near bodies of water etc.). Avoid penetration of liquids or moisture as this may cause short circuit and/or damage to the battery. If liquid does get into the device, remove the battery immediately and contact the authorized service center.

Do not leave the device for a long time in poorly ventilated environment, e.g. in a car or in closed tight boxes/packaging.

Avoid exposure to strong electromagnetic fields.

Neither drop nor try to bend the device. If the device is damaged contact the authorized service center.

Do not disassemble or modify the book reader. Only authorized personnel may conduct work on the device.

This device is not waterproof and must not be used under water. If your device has become wet contact the authorized center immediately.

Do not use the device with a damaged battery, charger (broken case, poor contact, broken feed cable) or SD card. If the battery is damaged (cracked case, leakage of electrolyte, off-shape etc.) it should be replaced.

Do not replace the battery yourself. Use of home-made or modified batteries may cause an explosion and/or damage the device.

Warning! Do not destroy the battery by burning it, to avoid the danger of explosion!

Avoid any mechanical pressure on the screen. Protect the screen from objects that may scratch or damage it. To ensure adequate protection of the screen, we recommend storing the device in a protective and/or hard cover.

Do not use organic or inorganic solvents (e.g. benzol etc.) to clean the screen/case. Use a soft cloth to remove dust from the device's surface. To remove dirt apply a few drops of distilled water. To remove persistent dirt contact the authorized center.

Do not expose the screen to electrostatic charges or artificial sources of UV electromagnetic radiation.

Up to five faulty pixels are acceptable in the screen and do not constitute a warrantable defect of the screen.

Never leave cables near heat sources. Heated cables or their insulation may become deformed or damaged, which could lead to fire or electric shock.

Avoid any mechanical impacts onto connectors and keys of the device. This may affect their operation and cause malfunction.

Disposal of electric and electronic components (the Directive is applicable to the EU and other European countries where separate waste disposal systems exist).



In other countries dispose batteries accordingly to local laws.

Incorrect disposal of this device may have adverse impacts on the environment and public health. To prevent such consequences follow the device-specific disposal requirements. Recycling of these materials helps preserve natural resources. For more information regarding recycling issues please contact local municipal

authorities, your domestic waste collection service, store where you purchased the device, or the authorized service center.

Do not use wireless communication in places where it is prohibited. Please, do not use wireless communication onboard a plane and in hospitals – this may affect airborne avionics or medical equipment.

This book reader receives and transmits radio frequencies and may interfere with radio communications and other electronic equipment. If you use personal medical devices (e.g. a pacemaker or hearing aid) please contact your doctor or the manufacturer to learn whether or not such medical devices are protected against external RF signals.

By the end of product guarantee term, please contact the nearest authorized service facility for examination on the subject of security is maintained.

Keep away from children.


Technical Characteristics

Display	7" Touch screen, TFT 800x600, 143 dpi, 262,000 colors
Processor	800 MHz
Memory	RAM: 256MB Flash: Micro SD card (2GB) up to 32GB.
Operating system	Android®
Communications	Mini USB (480 Mb/s), Wi-Fi® (b/g/n)
Memory Slot	External memory slot SD (SDHC) up to 32GB
Audio Output	Connector 3.5 mm earphones; 2 x 0.5 W speakers
Accelerometer	Yes
Book formats	PDF (ADOBE DRM), EPUB (ADOBE DRM), PDF, EPUB, FB2, TXT, DJVU, RTE, HTML, DOC, DOCX, FB2, ZIP
Image formats	JPEG, PNG, GIF
Audio formats	MP3, AAC, MIDI, OGG
Video Formats	3GP (codecs H.263, MPEG-4 SP), MP4 (codecs H.263, MPEG-4 SP, H.264 AVC (Baseline Profile (BP)))
Battery	Li-Polymer, 7.4V, 1600 mAh
Charger	12V / 1.5A
Size	144x192x14 mm
Weight	516 g


Appearance and Controls

This section provides a general description of your PocketBook IQ 701 and its functional keys.

Front view:



Back view:



Controls and Indicators

1. **'On/Off'** – switches the device on/off (long pressing)
2. **'Menu'** – brings up quick menu
3. **'Home'** – return to Home Screen
4. **'Return'** – back to the previous menu, close the book
5. **'Volume +'** – increasing volume
6. **'Volume -'** – decreasing volume
7. **Speakers** – 2x0.5 W speakers
8. **Power connector** – designed for charging your device from the mains
9. **3.5 mm Audio Jack** – designed for connecting 3.5 mm earphones
10. **Color indicator** – designed for indicating the device charging status. Steady orange indicator light that charging in progress, constant green – battery fully charged
11. **'Reset'** – reloads the device
12. **Mini-USB** connector – designed for connecting your device to PC
13. SD card slot is used to connect an external SD memory card (SD card is optional).

Getting Started

STEP 1. CHARGING THE BATTERY

Charge your device for 8-12 hours for the first time. During the first charge, the device should be kept off. To charge the battery for the first time:

1. Make sure the device and its power indicator are off. If it is on, keep the 'On/Off' button pressed for a few seconds
2. Select 'Power Off' on the context menu, that appears
3. Connect your device to the mains using the charger
4. The indicator turns orange as soon as the charging process starts
5. When the battery is fully charged, the indicator turns green
6. Now you can disconnect the device from the power line, and turn it on for the first time.

STEP 2. TURNING ON

Keep 'On/Off' pressed for about 2 seconds. A startup logo appears

When the device is ready to operate, the image will be replaced by the lockscreen. The lockscreen can be unlocked in two ways: either by pressing the Menu button on the front

panel or by touching the lock icon in the screen and sliding your finger over the screen in the direction indicated by



the arrow, till the screen becomes unlocked. After unlocking, the main screen will open on the Home screen.

STEP 3. SETTINGS

Follow the Wizard instructions to customize the main parameters. After finishing the customization, Home Screen will appear.

STEP 4. READING BOOKS

Your PocketBook IQ 701 already stores hundreds of books of various genres and styles in different languages. . For more information on how to add new books to your library, see '[Loading and reading e-books](#)'.

User Manual

The *User Manual* is stored in the internal memory of your device, so you may refer to detailed description of functions you need at any time.

User Manual for the latest firmware version also available on the PocketBook official website:

http://pocketbook-int.com/support/pocketbook-IQ_701/

Navigation

Selection of Items and Starting Applications

To invoke the desired menu item or run the application, simply touch its icon or list item on the screen with your finger or stylus. To return to a previous screen, just click the 'Return' button on the front panel. This action will minimize the application, but not close it.


Quick menu is brought up by pressing 'Menu' button on the front panel. Context menu of element or section is brought up by long touch on it.

Home Screen

Home screen consists of 5 desktops. To scroll the Home screen, move your finger across the screen or tip the counter icon in the left or right corner of the screen. Continuous touch on one of them brings up the thumbnails of all five desktops for quick switching between them.

Desktop may contain shortcuts, widgets and control panels.

By default three desktops are filled with widgets and shortcuts described below. In the bottom of screen next starters are located:



- **Home** – brings up the central desktop
- **Applications** – opens applications panel
- **Browser** – opens the web browser. If browser already opened, it will be opened in current state.
- **Recycle Bin** – starter is activated after continuo's touch on icon or widget. To delete element, drag-and-drop it to Recycle Bin and release after it highlights in red.

Continuous touch on the free screen brings up context menu, where you can customize interface to your own adding different elements to a desktop. Context menu contains such options:

- **Shortcuts**

- Applications
- Bookmarks
- Music playlist
- Settings

- **Widgets**

- Analog clock
- Continue Reading
- Music
- Picture frame – crops an image to place it on a desktop
- **Power Control** – optimizing the power consumption of the device. Has such options:
 - Wi-Fi
 - Synchronization – controls background synchronization (e.g. for email application)
 - Brightness – 3 levels of screen illumination
- **Search** – Google search.

- **Folders**

- New folder
- BookShelf

- **Wallpapers**

- Pictures – set user image as wallpaper
- Wallpaper – choose wallpaper from standard collection.

‘Menu’ button brings up quick desktop menu, which contains next options:

- **Add** – context desktop menu
- **Wallpapers** – set desktop wallpaper
- **Search**
- **Notifications** – brings up notification panel
- **Settings**

Status Bar

The status bar, located at the top of the screen, shows:


- date and time
- battery status
- information about current connection:
 - wireless network

- computer via USB.



 **Mon 4/18/2011, 15:59**

The status bar also may show system notification icons. These notifications can be viewed by expanding the status bar: press and hold your finger (or stylus) on the status bar and pull it down to the bottom of the screen.



Panel of Running Applications

The panel contains a list of currently running applications.

To display this panel, press and hold the 'Home' button

Using the panel, you can switch to another opened application.

Using the On-Screen Keyboard

To access the on-screen keyboard, touch any textbox.

The screen will display a standard keyboard. Enter your text by touching the keys of the on-screen keyboard.

To access keyboard options, press and hold '123' button. This will bring up menu with next options:

- Vibrate on keypress
- Sound on keypress
- Auto-capitalization
- Input languages – select necessary input languages and press 'Return' button
- Quick fixes
- Show suggestions
- Auto-complete.

To change input language, slide your finger over the Space button.



Software Functions

To access application list, press Applications starter on the bottom of Home screen.

This panel displays all installed applications. PocketBook IQ 701 lets you install any programs designed for the Android® operating system except those which utilize any modules or functions which are not available in the device.

The software package includes a number of default applications such as DolphinBrowserHD and OperaMini which can be installed by the user using the File Manager: /PocketBook701/app.

The programs can be installed manually by copying the installation package to the device and running the installation wizard from File Manager.

Library



To enter Library, tap the 'Books' icon in the Main panel.

This section shows all books, magazines and other documents on the internal memory and SD card (if installed).

Note: *Files in media formats (i.e. music, video etc.) are not displayed in the Library. To access these files, use the [File Manager](#)*

Main functions:

- ✓ Search/opening books and other documents
- ✓ Managing the section content via Context Menu
- ✓ Accessing the 'BookLand' online library.

Bookshelves

Default Library view mode.

To create new shelf, select appropriate option from quick menu ('Menu' button). Using 'Shelves' option from the quick menu, you can set correspondence of the books to various bookshelves. The book can be on the different bookshelves simultaneously.

You can search books by title or author, arrange books in accordance with your preferences (thumbnails of the books or in the form of a list).

Working with Folders and Files

To open a folder, tap on its title. To collapse all the contents back, tap its title again.

To open a file – tap on its title. If this file is registered in the system, it will be opened by appropriate reader.

Working with Books and Bookshelves

To view the contents of a bookshelf, simply touch its title. Tap this title again to close this bookshelf.

To open a book, touch its title. The library displays books only in those formats that can be read by the device.

Quick Menu


To enter quick menu, press 'Menu' button. The quick menu provides the following functions:

- **Search** – by title or author
- **Sorting:**
 - by Title
 - by Author
 - by Date.

Sorting function is not operable in the 'History' tab of the 'Library' section.

- **Table Thumbnails/List View**
- **Add shelf**

- **Folders/Shelves** – toggles library display mode. Bookshelves – used for working with book files installed on the device. Files – used for working with all files on the device
- **Downloads** (opens a folder with downloads from the 'BookLand' online library and other files).



Managing Books in the Library

Press continuously on a book to bring up context menu.

- **Open**
- **Rename**
- **Delete** – physically deletes a book
- **Add to Favorites/Remove from Favorites**
- **Mark as unread/Mark as read**
- **Shelves**
- **View Info.**

***Note** Certain commands enabled in 'Bookshelves' mode only.*

Online library 'BookLand'

PocketBook IQ 701 allows you to browse and download books from the 'BookLand' online bookstore. The device accesses the library services via wireless Internet connection. Wi-Fi.

To enter the online library, go to 'Online' Library tab.

Main functions:

- ✓ Log on to/user registration in the library
- ✓ Browse, manage book shelves/content
- ✓ Access to new books and bestsellers in store or free library
- ✓ Book search in the catalog
- ✓ Overview of popular authors
- ✓ Overview of ways to replenish your balance in the 'BookLand' library.

Accessing the books in the BookLand

1. Open the 'Library' section by pressing the 'Library' button in the main menu
2. Touch the 'Online' tab with your stylus



3. Select the desired book by using the 'BookLand' store's browsing tools. In the menu of the 'BookLand' section select what you need.

Note *To connect to the bookstore, the device must have preconfigured Internet connection.*

Search in the library

You can perform book search by book title.

Press the '**Menu**' button to call the library's quick access menu. Press the '**Search**' icon.

The screen will display the search query box and the on-screen keyboard.

Enter your search query in the textbox. The search is performed by book. Results are displayed briefly (title and author) as you type.

Upon starting the search (the button with magnifying glass image near the textbox), the result will be displayed completely: cover page, book title, and author.

Dictionary



Allows you to translate a word, selected in read mode or entered from keyboard, using available dictionaries. After launching the application, the onscreen keyboard will appear (see the '[Using onscreen keyboard](#)' section for detailed information on how to use the keyboard). Type in the required word and the application will find the translation. You can turn pages of the dictionary. If you have several dictionaries on your PocketBook IQ 701, you can switch between dictionaries.

Dictionary installation/uninstallation

To install dictionary, perform the following:

1. Copy dictionary file on the device
2. Open File Manager
3. Find dictionary file on the device
4. Launch file and confirm dictionary installation.

To remove dictionary, open section Settings > Applications > Manage packages.

Select package to remove and confirm uninstallation.

Office Applications

- **Notes** – application for creation/edition text and graphic notes
- **Calendar**
- **Alarm clock** – supports several alarms depending on day of the week. After setup, alarm icon will be displayed in status bar
- **Calculator** – supports several engineering functions. To use additional functions, press 'Menu' button and select 'Additional panel'

Multimedia Content Management

- **Gallery** – application for image viewing. Also, this program supports next features: crop image, set as wallpaper, send by email and delete.
- **Music** – application for playing music. Program supports playlists creation and grouping tracks by artists and albums
- **Video** – application for playing video. Next video formats are supported recently: 3GP (codecs H.263, MPEG-4 SP), MP4 (codecs H.263, MPEG-4 SP, H.264 AVC (Baseline Profile (BP))).

Internet

Browser



Browser supports several windows and zooming. To open zoom menu, touch and hold free part of web-page. Quick browser menu has following options:

- New window
- Bookmarks
- Windows – lists all opened browser windows or opens new one
- Refresh/Stop
- Forward
- More
 - Add bookmark
 - Find on page
 - Select text
 - Page info
 - Downloads
 - Settings

Note Downloads are possible if external SD card inserted.

BOOKMARKS

This section consists of 3 tabs:

- Bookmarks – list of bookmarked web-pages. Quick menu allows to add current page to bookmarks, and toggle between thumbnail and list view mode
- Most visited
- History – quick menu allows to clear history.

Also you can add page to bookmarks by clicking on star icon on the right side from web-page title in Most visited and History sections.

Depending on tab, next operations with page are available in context menu:

- Open
- Open in new window
- Add bookmark
- Change bookmark
- Add shortcut to Home
- Share link
- Copy link URL
- Delete bookmark
- Set as homepage

Browser Settings

PAGE CONTENT SETTINGS

- Text size
- Default zoom
- Open pages in overview – opens page on the screen width
- Text encoding
- Block pop-up windows
- Load images
- Auto-fit pages
- Landscape-only display – displays web-pages in landscape view only, overcoming the accelerometer
- Enable JavaScript
- Open in background
- Set homepage

PRIVACY SETTINGS

- Clear cache
- Clear history
- Accept cookies
- Clear all cookie data
- Remember form data
- Enable location
- Clear location access

SECURITY SETTINGS

- Remember passwords
- Clear passwords
- Show security warnings

ADVANCED SETTINGS

- Website settings – view extra settings for particular web-pages (if available)
- Reset to default

Email



Standard email application. At the first time, you will be suggested to enter your account information and set up incoming server settings. These settings should be provided by your email service.

Note *Incoming server settings for Gmail are preconfigured.*

Email client supports several accounts.

Account settings:

- Account name
- Your name – will be displayed in field 'From'
- Email check frequency
- Default account – sets selected account as default
- Email notification
- Select ringtone
- Vibrate
- Incoming/Outgoing server settings

File Manager



Initially application has 3 tabs, displaying files and folders: Home, sdcard and PocketBook701. To open folder or file, just tap its icon. To go up one level, press '..' string or press 'Return' button .

Context menu has next options:

- Open in new tab (for folders)
- Move
- Copy – in each folder 'Copy here' button will be displayed
- Rename
- Delete
- Open with proper application, depending on file type (e.g. Reader for books, Gallery for images etc.)

On the top located quick launch buttons:

- Favorites
- Home
- Up to one level
- Create folder

- Copy
- Search

You can select several files or folders by checking checkboxes on a left from file/folder name and press Copy button. For multiple selections, next options available in context menu:

- Move
- Copy
- Delete
- Add to zip archive
- Cancel

Context menu of tab title has next options:

- Add to favorites

Note *File Manager favorites are not the same as Reader or Browser ones*

- Favorites
- Close Tab

File Manager quick menu:

- Favorites
- Close tab
- Search files

- New folder
- Settings
 - Show hidden files

Advanced

These applications are for users, experienced in OS Android. Manufacturer is not responsible for malfunction of the device, caused by improper usage of these applications. For more information, see [OS Android developers' official website](#).

- AndroidAppClientsList – client for access to Android applications webstores. Needs access to Internet.
- SAM – client for 'Slide Me' application store
- Screen Calibration – sets up the sensor screen. Tap on crosses, appearing on the screen

Default applications collection also contains **Sudoku** – popular Japanese puzzle.

Loading and Reading books

Loading Books to the Memory

Connect your device to PC via mini-USB cable. Internal memory and external SD card will be displayed in Windows Explorer or any file manager of another application. Copy books to the selected folder to the device memory or to the SD card.

Loading Protected Books (DRM)

You can download protected books in two ways.

LOADING BOOKS VIA .ACSM LINK

- Visit website www.adobe.com using your PC browser
- Enter (Products) section
- In alphabet list go to link 'Digital Editions'
- To enter library, go to 'Visit Sample eBook Library'
- Select book
- Press 'Download Item'
- Save .acsm file to your PC

Note You can follow similar instructions to download link to protected book from any online bookstore.

To open protected book, do the following:

- Copy book link (.acsm) file to external memory card.
- Find and open this file using the File Manager
- Activate your device following the on-screen instructions. Enter your www.adobe.com account information in 'Activation' form. After that you will be able to download book.

Full version of the book will be available for reading in Digital Edition folder.

Loaded book is protected and cannot be opened by unregistered user.

LOADING BOOKS VIA PC

- Open application 'Adobe Digital Editions'

Note Application will ask you to activate the device after you connect it for the first time. Use your www.adobe.com account information to proceed.

- Switch to library view ('Go to Library View')
- Press 'All items'
- Find a book and copy it to the device (you can just drag-and-drop it to the device icon). To open it, use your account information on www.adobe.com.

Note You won't be able to copy book using 'Adobe Digital Editions' if your device is not activated.

Open a Book

To open a book, enter 'Library' and select the required book. Recently opened book can be opened from Continue Reading widget on the Home screen. If you have already started to read this book, it will be opened on a page at which it was closed.

Reading Mode

In reading mode, the corresponding viewing program opens the selected file. Main features:

- ✓ Paging
- ✓ Display rotation
- ✓ Zoom
- ✓ Switching to specified page
- ✓ Linking inside the book
- ✓ Bookmark managing
- ✓ Notes managing
- ✓ Switch to Structured Table of Contents
- ✓ Adding to Favorites
- ✓ Marking book as read/unread
- ✓ Viewing book info
- ✓ Display configuration.

PAGING


To go to the next or previous page, slide your finger or stylus in direction, opposite to where you want to go. This movement is similar to page turning when you are reading a paper book.

Paging is also available in the main operation menu. To open main operation menu, tap on the status bar at the bottom of the screen, when you are reading a book.

When reading books in PDF and DJVU formats, if content does not fit the page, you can move the image. To move the image, press and hold your finger in the centre on the display and move the image.

Panel of Basic Commands

To call the command panel, just touch the **Status bar**.



LOCKING SCREEN ROTATION

Selecting this function, you can lock and unlock the current screen position, overcoming accelerometer.

FIT TO WIDTH

For graphic format files. This function restores the book display scale using a page size equal to screen width.

ZOOMING

You can select a desired scale for the displayed document. To do this, call the basic commands menu and, using the '+' and '-' buttons.

REFLOW

Zooming mode changing the font size. To enter this mode, bring up the context menu holding the finger in the center of the screen, and select 'Reflow' option. Change font size using command panel '+' and '-' buttons. To exit reflow mode, select 'Hard page' context menu option.

CURRENT PAGE AND TURNING PAGES

The cells of right-hand side of the command panel display page-turning arrows, current page, and total number of pages. You can turn the pages by pressing the arrows.

To go to the specified page, press the cell with the current page number with your finger or stylus and then use the on-screen keyboard to enter the page number you want to go to in the opened textbox 'Go to page'.

Note: Scale changing or menu calling is accompanied by changes of the visible screen area and the reader recalculates the total number of pages in the book. This can take some time.

Linking Inside the Book


Some book formats allow you to link inside a book. References in the text are highlighted. To go to the link, press and hold the required link (use stylus for greater precision).

The reference will open as a separate page. To return to the book, press the 'Return' button

Quick Menu

To access the Quick Menu, click the "Menu" button on the device's front panel.

Note Some of quick menu features may not be supported in particular file types, such as EPUB or PDF, especially protected.



BOOKMARK MANAGING

To create a bookmark, press and hold in the centre of the display. The quick menu will appear. Select 'Create bookmark'. To view bookmarks, open the main operation menu and select the 'Bookmark' icon. Select desired bookmark in the displayed list.

NOTES MANAGING

From time to time you may find it useful to save a selected fragment to a separate notepad. To create a new note in the reading mode, bring up the Quick Menu by pressing the "Menu" button and clicking on the "Note" icon.

If a text format book is open, the notepad will show the editable page text for saving. You can add comments to the text or delete any unnecessary fragments, using the on-screen keyboard, before saving the note for further reference and usage.

If a graphic format book is open, the notepad will show a screenshot of the page fragment being viewed. Using drawing tools, you can make notes on a page screenshot and save it as an image for further reference and usage.

SWITCHING TO STRUCTURED TABLE OF CONTENTS

The contents displays the names of chapters and sections of the book. To go to a selected chapter, press its name with your finger or stylus.

Contents can have hierarchical structure of chapters, sections and parts. Sections with hidden parts of the structure are designated by arrows. To expand a hidden branch, click the arrow.

DICTIONARY

Touch the word you want to translate in a page with your finger (or stylus) or enter it using the on-screen keyboard.

Press '**Enter Word**' button to type a word for translation in the textbox by yourself.

SEARCH

To find the desired words or parts of words in the text quickly, click the search button in the shortcut menu. Using the on-screen keyboard, enter the text to search for and click "Search". Search results will be highlighted in color.

The control panel search results appear at the bottom of the screen. Use the arrows to navigate through the pages of search results.

TEXT TO SPEECH

The Text-to-speech function or TTS is used to transform text information into speaker voice sounds.

To enable the text-to-speech function, do the following:

Press and hold on the screen until the menu will appear, and select '**Text to speech**'.



More

Add to Favorites

View Info

Text to Speech

Night Reading

Settings

The TTS control menu will be displayed at the bottom of the opened book.

Highlight a sentence in the text for playback.

- Press "Play" to start speech reproduction
- Use the fast forward and rewind buttons to select further sentences for playback
- Use the volume controls to adjust playback volume

from Meryton, denominated from that period Lucas Lodge, where he could think with pleasure of his own importance, and, unshackled by business, occupy himself solely in being civil to all the world. For, though elated by his rank, it did not render him supercilious; on the contrary, he was all attention to everybody. By nature inoffensive, friendly, and obliging, his presentation at St. James's had made him courteous.


Lady Lucas was a very good kind of woman, not too clever to be a valuable neighbour to Mrs. Bennet. They had several children. The eldest of them, a sensible, intelligent young woman, about twenty-seven, was Elizabeth's intimate friend.

That the Miss Lucases and the Miss Bennets should meet to talk over a ball was absolutely necessary; and the morning after the assembly brought



To select the playback language, press the tongue icon on the left of the TTS control panel.

Select the desired playback language from the list of available ones.

 Select language

German

English

Spanish

French

Italian

Note Some of the text-to-speech mode settings are available in the "[Settings](#)" section

Note The Text-to-Speech function becomes accessible for an opened book only after page calculation.

Note The currently reproduced sentence text is highlighted. Pages of the book reproduced by voice are flipped automatically.

BOOK INFO

To view book info open the quick menu by pressing and holding the stylus or your finger in the centre of the display.

From the displayed list select 'View info' option. Information on the book is displayed, such as title, author, cover page, full path, and file size.

NIGHT READING

Turns the night reading mode on/off. In this mode, book will be displayed as white text on a dark background. This will decrease scattered light from the device.

CONFIGURATION

To open the Settings menu in reading mode, go to the extended option menu 'More' and select the 'Settings' option.

Here you can configure:

- **Panel menu lock** – locks/unlocks the main operation menu in current status (opened/ hidden), overcoming the accelerometer
- **Full screen** – turns full screen viewing mode on/off (hides menu panel)
- **Volume key scrolling** – activates/deactivates buttons '+' and '-' used for paging while reading;
- **Font size** –selects font size.

Closing the book

To close a book press 'Return' or 'Home' button.

Settings

To access Settings, select icon in Home screen quick menu or in application panel. In this section:

- Set the interface language and font
- Activate and deactivate internal functions of the device
- Customize the power saving mode
- Manage the services and installed programs
- Browse the device, memory and operating system status and set the current time and date.

Wireless & networks

- **Flight mode** – disables all wireless connections
- **Wi-Fi** – start scanning for Wi-Fi networks
- **Wi-Fi settings**
 - Wi-Fi enable/disable
 - Network notification – notify on open network found
 - Add Wi-Fi network.

By checking the 'Network Notification' option you can make your device scan the air for available Wi-Fi access points. Your device will offer you a list of available networks. If the 'Network Notification' option is disabled, you can scan the air by calling up the quick access menu in 'Wi-Fi Settings' and pressing the 'Search' button.

You can scan available Wi-Fi networks by bringing up the context menu and selecting 'Scan'.

To configure additional parameters, bring up quick menu and select 'Advanced'. Here you can find:

- Regulatory domain. Setting the number of channels to use
- Wi-Fi sleep policy. Selects conditions to switch Wi-Fi to standby mode
- MAC address. Shows MAC address of the device.

To connect to the network manually, click 'Add Wi-Fi network' option in 'Wi-Fi settings' sub-menu. In the opened window, click the 'Network SSID' box and enter network SSID name using the on-screen keyboard.

Below, you will find a drop-down list to select a network protection method. 'No Protection' option is set by default. Enter the access password using the on-screen keyboard in textbox pops-up after protection method selection.

To simplify entering the password, you can check the 'Display password' box – in this case entered characters will not be automatically hidden. Be careful – outsiders will be able to see your password and use it for unauthorized access.

After setting up all the required settings, press the 'Save' button and the network with specified settings will be displayed in your list of networks. To connect to this network, find it in your list of networks, click it and select the 'Connect' option.

VPN SETTINGS

Here you can set up and manage Virtual Private Networks (VPNs) of next types:

- PPTP
- L2TP
- L2TP/IPSec PSK
- L2TP/IPSec CRT.

Sounds & display

- Sound settings:
 - **Silent mode** – disables all sounds except media and alarms
 - **Media volume** – adjusts volume for music and videos
 - **SD card notifications**– sound notifications on insertion/removal of SD card.
- Display settings:
 - **Orientation** – automatic screen rotation for reading with maximum comfort
 - **Animation** – animation level in the device
 - **Brightness** – adjusts the brightness of the screen
 - **Screen timeout** – adjusts the delay before the screen automatically turns off.

Applications

- **Unknown sources** – allows installation of applications obtained from any other sources beside Android Market.
- **Manage applications** – lists installed applications, displays their parameters and access rights, uninstalls applications and controls their operation (force quit)
- **Running services** – lists and manages currently running services
- **Manage packages** – lists dictionaries and text-to-speech packages, installed on a system.

Accounts & sync

- **Background data** – allows applications to sync, send, and receive data at any time
- **Auto-sync** – allows applications to synchronize automatically
- **Add account** – adds an email account

Privacy

- **Factory data reset** – returns the system to its initial state.

The following information will be erased:

- Your Google account settings
- System data and settings
- Downloaded and installed applications
- Action will not affect system software and data on SD card.

SD card and memory

Here you can view

- Total space
- Available space

SD card Management :

Memory card operations:

- **Unmount SD card** – safely removes SD card from file system. After it you may remove it from its slot
- **Format SD card** – erases **all data** from your SD card. The card should be unmounted using Unmont SD card at first.

Language & keyboard

- **Select locale** – changes the interface language; keyboard layout. Date, time and numbers formats are customized separately
- **Android keyboard** – [on-screen keyboard settings](#)
- **User dictionary** – adds/removes words from user dictionary for spellcheck.

Text-to-Speech

- **Always Use My Settings** – override the application settings with the user's preferences
- **Text Speed** – sets text playback speed
- **Language** – sets the default playback language.

Date and time

- **Set date**
- **Select time zone**
- **Set time**
- **Use 24-hour format**
- **Select date format**

About device

Here you can find detailed information about your device:

- **Model number**
- **Firmware version**
- **S/N** – device serial number.

Troubleshooting

MALFUNCTION: Device does not turn on or turns on but only the logo loads

POSSIBLE CAUSE: battery is low.

SOLUTION: charge the battery.

MALFUNCTION: A book does not open - the message 'book is probably damaged or protected' appears, or nothing happens at all.

POSSIBLE CAUSE: this book is damaged.

SOLUTION: If the book was downloaded from the online store try to re-load it again. If the file opens on your PC, but does not open on the device, resave the book in another format.

MALFUNCTION: No response when you press any key.

POSSIBLE CAUSE: sometimes (e.g., when downloading damaged or books with too large a volume) the device may 'hangup'.

SOLUTION: close the frozen application by pressing the 'Return' key for 1–2 sec. If this doesn't help, press 'Reset' on the rear panel to reload your device.

PROBLEM: Having connected to PC, no disks of the device are seen in WINDOWS Explorer.

POSSIBLE CAUSE: no signal in connection cable.

SOLUTION: check USB cable condition and its proper connection to connector. Try to connect the USB-cable to another connector.

PROBLEM: Bookmarks, settings and current position in file are not saving.

POSSIBLE CAUSE: damaged file system.

SOLUTION: connect the device to a PC and check disks. To do this, open 'My Computer', right-click on the selected disk and select 'Properties – Service – Check Disk'.

POSSIBLE CAUSE: internal memory overloaded.

SOLUTION: Delete books, images and/or music files that you do not need.

PROBLEM: Battery discharges too fast.

POSSIBLE CAUSE 1: disabled automatic turning off.

SOLUTION: select 'Configuration' ⇒ 'Clock' in Main Menu. Select automatic turn off time (10, 20, 30 or 60 minutes) for the 'Turn Off in...' item.

POSSIBLE CAUSE 2: music player is in background mode. The music player is the most energy-consuming application. A

tone icon in the right lower corner indicates that the player is active.

SOLUTION: turn off the player.

PROBLEM: Another version of firmware is beeing installed on the device.

POSSIBLE CAUSE 1: An older version of firmware is in internal memory.

SOLUTION: Delete the old firmware file from the root folder of the device's internal memory.

POSSIBLE CAUSE 2:

Two or more firmware files are present. Each version of firmware has a unique name; thereforer, several of them could reside at the same time in root directory of both SD card and internal memory. The system will run the firmware it finds first.

SOLUTION: Prior to copying a new firmware file for installation, find and delete all old firmware files in roots of both SD card and internal memory matching the mask: `"*_PB701SWUPDATE.zip"`

Customer Support

For detailed information about service centers in your country please visit the official website of PocketBook International: <http://www.pocketbook-int.com>.

Software Version Update

Upgrade is possible only from version 2.0.6. If your device has older firmware version, you should update it to version 2.0.6 first.

To update firmware, download new firmware from [PocketBook](#) website. Go to 'Support' section and select 'PocketBook IQ 701' model. Select last version (2.1.*) from 'Firmware' section.

To install the firmware, perform the following steps:

1. Copy the firmware archive file to an external SD card. The archive should not be unpacked
2. Turn off the device completely
3. Connect the device to power supply using the charger to avoid problems caused by battery discharge during update process
4. Press and hold '**Volume +**' button on the sidebar
5. Press '**On/Off**' button, holding '**Volume +**'
6. Release the buttons after device starts. All the firmware update operations will be implemented automatically, and device will restart
7. Set up the initial settings following Wizard instructions

Note *The firmware version may be found in section Settings > About device > Firmware version*

Compliance with International Standards

The EUT should only be connected by adapter to a complied Limited Power Source. The adapter supplier/model and power supply specification:

AC Power:

Manufacturer: Huntkey

Model: HKA01812015-2D/3D

Rated output voltage: DC 12V 1.5A)



This equipment is marked with the 0984 symbol and can be used throughout the European community.

This indicates compliance with the R&TTE Directive 1999/5/EC and meets the relevant parts of the following technical specifications:

- EN 300 328 V1.7.1 – Electromagnetic compatibility and Radio spectrum Matters (ERM); Wideband Transmission Systems; Data transport equipment operating in the 2.4 GHz ISM band and using wide band modulation techniques; Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive
- EN 301 489-1 V1.8.1 - Electromagnetic compatibility and Radio spectrum Matters (ERM); ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements
- ETSI EN 301 489-7 V1.2.1 Electromagnetic compatibility and Radio spectrum Matters (ERM); ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 7: Specific conditions for mobile and portable radio and ancillary equipment of digital cellular radio telecommunications systems (GSM and DCS)
- EN 301 489-17 V2.1.1 - Electromagnetic compatibility and Radio spectrum Matters (ERM); EMC standard for radio equipment and services; Part 17: Specific conditions for 2.4 GHz wideband transmission systems and 5 GHz high performance RLAN equipment
- ETSI EN 301 489-24 V1.4.1- Electromagnetic compatibility and Radio spectrum Matters (ERM); ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 24: Specific conditions for IMT-2000 CDMA Direct Spread (UTRA) for Mobile and portable (UE) radio and ancillary equipment
- ETSI EN 301 511 V9.0.2 - Global System for Mobile communications (GSM); Harmonized EN for mobile stations in the GSM 900 and GSM 1 800 bands covering essential requirements under article 3.2 of the R&TTE directive (1999/5/EC)

- ETSI EN 301 908-1 V3.2.1 - Electromagnetic compatibility and Radio spectrum Matters (ERM); Base Stations (BS), Repeaters and User Equipment (UE) for IMT-2000 Third-Generation cellular networks; Part 1: Harmonized EN for IMT-2000, introduction and common requirements, covering essential requirements of article 3.2 of the R&TTE Directive
- EN60950-1:2006+A11:2009 - Information technology equipment - Safety - Part 1: General requirements
- EN 62311: 2008 - Assessment of electronic and electrical equipment related to human exposure restrictions for electromagnetic fields (0 Hz-300 GHz)

France - 2.4GHz for Metropolitan France:

In all Metropolitan departments, wireless LAN frequencies can be used under the following conditions, either for public or private use:

- Indoor use: maximum power (EIRP*) of 100 mW for the entire 2400-2483.5 MHz frequency band
- Outdoor use: maximum power (EIRP*) of 100 mW for the 2400-2454 MHz band and with maximum power (EIRP*) of 10 mW for the 2454-2483 MHz band.

Important: Changes or modifications to this product not authorized could void the EMC and wireless compliance and negate your authority to operate the product. This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The device was tested and complies to measurement standards and procedures specified in FCC OET Bulletin 65, Supplement C

Certification information (SAR) The device meets guidelines for exposure to radio waves.

Your device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network.

The highest SAR value under the ICNIRP

Band	Channel	EU 10g SAR Limit	Highest 10g SAR Value
802.11 b	7	2 W/kg	0.265 W/kg

This equipment complies with the European Council Recommendation of 12 July 1999 on the Limitation of Exposure of the General Public to Electromagnetic Fields [1999/519/EC].

Assembled in China

Designed by Pocketbook Int. Room 2201, 22/F.1 Duddell str. Central, Hong Kong

“Contains Reader® Mobile technology by Adobe Systems Incorporated”